



# AUTOMATIC BARBECUE SHUT-OFF TIMER




RATED UP TO 100,000 BTU's  
MAX TEMPERATURE 125° F

Item # SOL-GASTIMER-3

Place the Automatic Barbecue Shut-Off Timer in the Gas supply line before the barbecue. The timer **MUST NOT** be placed in the barbecue enclosure.

**IMPORTANT:** Ensure you connect gas supply to the side marked "IN" on timer (see above).

Use pipe joint compound on male fittings attached to the timer  
To use, simply set the dial (turn clockwise) to the desired time to shut off. The dial is marked in 3 one hour increments (any position in between is an estimate of that hour). The timer dial will auto rotate (counter-clockwise) and will shut off the gas supply when the dial reaches "OFF" (i.e. the time is completed).



Rasmussen Gas Logs & Grills, 12028 Philadelphia Street, Whittier, CA 90601 USA  
562-696-8718 [info@rasmussen.biz](mailto:info@rasmussen.biz) [www.Rasmussen.biz](http://www.Rasmussen.biz)