

Shelves Kit for Solaire Portable Stand and Tripod

SOL-SHLV17A



Solaire "Anywhere" Grill
SOL-IR17-B



12028 E. PHILADELPHIA ST. WHITTIER CALIFORNIA 90601 U.S.A. www.rasmussen.biz



Solaire "Everywhere" Grill
SOL-EV17-A

Installing front and side shelves on an Anywhere Grill / Tripod combination


STEP ONE: With Anywhere Grill mounted on Tripod Mounting plate, remove feet and fit each with a with a 5/16-18 nut (Figure 1A) and plate washer Figure 1B). Then screw foot assemblies back into threaded holes in base channels of grill (Figure 3A). Leave approximately 1/4" space between plate washer and channel.

FIGURE 1




STEP TWO: Slide side shelf in place on left side of grill between washer and base channel of grill Figure 2A and Figure 3A, then slide front shelf in place on front side of grill Figure 3B, insuring that front shelf overlaps top of front corner of side shelf Figure 3C. Tighten all four feet to hold shelves in place.

FIGURE 2



Shelves will fit in place on front and left side of grill.

FIGURE 3



Installing front and side shelves on an Anywhere Grill / Portable Grill Stand combination

STEP ONE: Fit each foot with a with 5/16-18 nut (Figure 4A) and plate washer Figure 4B). Then screw foot assemblies into threaded holes in base channels of grill. Leave approximately 1/4" space between plate washer and channel to ease assembly to top angle of stand (Figure 4C).

FIGURE 5





FIGURE 4




STEP TWO: Slide side shelf in place on left side of grill between washer and base channel of grill Figure 4C and Figure 5A, then slide front shelf in place on front side of grill Figure 5C, insuring that front shelf overlaps top of front corner of side shelf Figure 5D. Tighten all four feet to hold shelves in place.

Installing front and side shelves on an Everywhere Grill / Tripod combination

With grill resting on Tripod Mounting Plate and feet loosely screwed into bottom of grill, slide left side shelf between underside of grill and Tripod Mounting Plate. Push shelf in until inside notch touches edge of grill foot (Figure 1A). Next, slide in front shelf (Figure 1B) in the same manner insuring that front shelf overlaps top of front corner of side shelf (Figure 1C). Tighten all four grill feet to hold shelves in place.

FIGURE 1



Installing front and side shelves on an Everywhere Grill / Portable Grill Stand combination

NOTE: If installing shelves onto an already assembled Portable Grill Stand (SOL-PST17A) first remove the front angle dress plate and loosen all four feet (1/8th to 1/4th inch).

Slide left side shelf between underside of grill and top side of grill stand. Grill should remain pushed back on stand and notches should line up (Figure 2A). Next, slide in front shelf (Figure 2B) in the same manner insuring that front shelf overlaps top of front corner of side shelf (Figure 2C). Tighten all four grill feet to hold shelves in place.

FIGURE 2

