



**Qty. Part number Description**  
**SOL-AGBQ-27GXL (9 volt battery system) – Right side rotisserie igniter placement**

1	SOL-6107R	Switch button
2	SOL-6103R	18" wire for switch
1	SOL-6106R	4 spark module
1	SOL-6104R	7" ground wire
1	SOL-6100R-HV	15" wire/electrode
1	SOL-6099R-HV	26" wire/electrode
1	SOL-6101R-HV	38" wire/electrode

**SOL-IRBQ-30 (AA battery system)**

1	SOL-6070R	Battery holder/button	
1	SOL-6071R	Positive wire	Unavailable (see * below)
1	SOL-6072R	Negative wire	Unavailable (see * below)
1	SOL-6057R	2 spark module	
1	SOL-6100R-HV	15" wire/electrode	
1	SOL-6099R-HV	26" wire/electrode	

\* If these wires need replacing, since they are no longer available, change spark module and battery holder to SOL-2859R and add 1 - SOL-6104R 7" Ground Wire.

**SOL-IRBQ-30 (9 volt battery system)**

1	SOL-6107R	Switch button
2	SOL-6103R	18" wire for switch
1	SOL-6105R	2 spark module
1	SOL-6100R-HV	15" wire/electrode
1	SOL-6099R-HV	26" wire/electrode

**SOL-AGBQ-30 (AA battery system)**

1	SOL-6070R	Battery holder/button	
1	SOL-6071R	Positive wire	Unavailable (see * below)
1	SOL-6072R	Negative wire	Unavailable (see * below)
1	SOL-6058R	4 spark module	
1	SOL-6104R	7" ground wire	
1	SOL-6100R-HV	15" wire/electrode	
1	SOL-6099R-HV	26" wire/electrode	
1	SOL-6102R-HV	72" wire/electrode	

\* If these wires need replacing, since they are no longer available, change spark module and battery holder to SOL-2859R and eliminate SOL-6104R 7" Ground Wire.

**SOL-AGBQ-30 (9 volt battery system) - Left side rotisserie igniter placement**

1	SOL-6107R	Switch button
2	SOL-6103R	18" wire for switch
1	SOL-6106R	4 spark module
1	SOL-6104R	7" ground wire
1	SOL-6100R-HV	15" wire/electrode
1	SOL-6099R-HV	26" wire/electrode
1	SOL-6102R-HV	72" wire/electrode

<u>Qty.</u>	<u>Part number</u>	<u>Description</u>	<u>List price</u>
<b>SOL-AGBQ-30 (9 volt battery system) - Right side rotisserie igniter placement</b>			
1	SOL-6107R	Switch button	
2	SOL-6103R	18" wire for switch	
1	SOL-6106R	4 spark module	
1	SOL-6104R	7" ground wire	
1	SOL-6100R-HV	15" wire/electrode	
1	SOL-6099R-HV	26" wire/electrode	
1	SOL-6101R-HV	38" wire/electrode	

<b>SOL-IRBQ-42 (AA battery system)</b>			
1	SOL-6070R	Battery holder/button	
1	SOL-6071R	Positive wire	Unavailable (see * below)
1	SOL-6072R	Negative wire	Unavailable (see * below)
1	SOL-6058R	4 spark module	
1	SOL-6104R	7" ground wire	
1	SOL-6100R-HV	15" wire/electrode	
1	SOL-6099R-HV	26" wire/electrode	
1	SOL-6101R-HV	38" wire/electrode	

\* If these wires need replacing, since they are no longer available, change spark module and battery holder to SOL-2859R and eliminate 1 - SOL-6104R 7" Ground Wire.

<b>SOL-IRBQ-42 (9 volt battery system)</b>			
1	SOL-6107R	Switch button	
2	SOL-6103R	18" wire for switch	
1	SOL-6106R	4 spark module	
1	SOL-6104R	7" ground wire	
1	SOL-6100R-HV	15" wire/electrode	
1	SOL-6099R-HV	26" wire/electrode	
1	SOL-6101R-HV	38" wire/electrode	

<b>SOL-AGBQ-42 (AA Battery system)</b>			
1	SOL-6070R	Battery holder/button	
1	SOL-6071R	Positive wire	Unavailable (see * below)
1	SOL-6072R	Negative wire	Unavailable (see * below)
1	SOL-6058R	4 spark module	
1	SOL-6104R	7" ground wire	
1	SOL-6100R-HV	15" wire/electrode	
1	SOL-6099R-HV	26" wire/electrode	
1	SOL-6101R-HV	38" wire/electrode	
1	SOL-6102R-HV	72" wire/electrode	

\* If these wires need replacing, since they are no longer available, change spark module and battery holder to SOL-2859R and eliminate 1 - SOL-6104R 7" Ground Wire. Rotisserie burner will need to be lighted manually with an Aim-n-Flame.

**Qty. Part number Description**  
**SOL-AGBQ-42 (9 volt battery system) - Left side rotisserie igniter placement**

1	SOL-6107R	Switch button
2	SOL-6103R	18" wire for switch
1	SOL-6106R	4 spark module
1	SOL-6100R-HV	15" wire/electrode
1	SOL-6099R-HV	26" wire/electrode
1	SOL-6101R-HV	38" wire/electrode
1	SOL-6102R-HV	72" wire/electrode

**SOL-AGBQ-42 (9 volt battery system) - Right side rotisserie igniter placement**

1	SOL-6107R	Switch button
2	SOL-6103R	18" wire for switch
1	SOL-6106R	4 spark module
1	SOL-6100R-HV	15" wire/electrode
1	SOL-6099R-HV	26" wire/electrode
2	SOL-6101R-HV	38" wire/electrode

**SOL-IRBQ-56 (AA battery system) – Grill Portion**

1	SOL-6070R	Battery holder/button	
1	SOL-6071R	Positive wire	Unavailable (see * below)
1	SOL-6072R	Negative wire	Unavailable (see * below)
1	SOL-6058R	4 spark module	
1	SOL-6104R	7" ground wire	
1	SOL-6100R-HV	15" wire/electrode	
1	SOL-6099R-HV	26" wire/electrode	
1	SOL-6101R-HV	38" wire/electrode	

\* If these wires need replacing, since they are no longer available, change spark module and battery holder to SOL-2859R and eliminate 1 - SOL-6104R 7" Ground Wire.

**SOL-IRBQ-56 (AA battery system) – Side Burner Portion**

1	SOL-6070R	Battery holder/button	
1	SOL-6071R	Positive wire	Unavailable (see * below)
1	SOL-6072R	Negative wire	Unavailable (see * below)
1	SOL-6057R	2 spark module	

\* If these wires need replacing, since they are no longer available, change spark module and battery holder to SOL-2859R and add 1 - SOL-6104R 7" Ground Wire.

**Qty.    Part number                      Description                                      List price**

**SOL-AGBQ-56                      (AA Battery system) – Grill portion**

1	SOL-6070R	Battery holder/button	
1	SOL-6071R	Positive wire	Unavailable (see * below)
1	SOL-6072R	Negative wire	Unavailable (see * below)
1	SOL-6058R	4 spark module	
1	SOL-6100R-HV	15” wire/electrode	
1	SOL-6099R-HV	26” wire/electrode	
1	SOL-6101R-HV	38” wire/electrode	
1	SOL-6102R-HV	72” wire/electrode	

\* If these wires need replacing, since they are no longer available, change spark module to SOL-2859R and eliminate 1 - SOL-6104R 7” Ground Wire. Rotisserie burner will need to be lighted manually with an Aim-n-Flame.

**SOL-AGBQ-56                      (AA Battery system) – Side Burner portion**

1	SOL-6070R	Battery holder/button	
1	SOL-6071R	Positive wire	Unavailable (see * below)
1	SOL-6072R	Negative wire	Unavailable (see * below)
1	SOL-6057R	2 spark module	

\* If these wires need replacing, since they are no longer available, change spark module and battery holder to SOL-2859R and add 1 - SOL-6104R 7” Ground Wire.

**SOL-AGBQ-56 (9 volt battery system) – Grill portion - Left side rotisserie igniter placement**

1	SOL-6107R	Switch button	
2	SOL-6103R	18” wire for switch	
1	SOL-6106R	4 spark module	
1	SOL-6100R-HV	15” wire/electrode	
1	SOL-6099R-HV	26” wire/electrode	
1	SOL-6101R-HV	38” wire/electrode	
1	SOL-6102R-HV	72” wire/electrode	

**SOL-AGBQ-56 (9 volt battery system) – Grill portion - Right side rotisserie igniter placement**

1	SOL-6107R	Switch button	
2	SOL-6103R	18” wire for switch	
1	SOL-6106R	4 spark module	
1	SOL-6100R-HV	15” wire/electrode	
1	SOL-6099R-HV	26” wire/electrode	
2	SOL-6101R-HV	38” wire/electrode	

**SOL-AGBQ-56 (9 volt battery system) – Side burner portion**

1	SOL-6107R	Switch button	
2	SOL-6103R	18” wire for switch	
1	SOL-6105R	2 spark module	