



The Creative Life

Firmware Update Instructions

WARNING!

Before updating, please confirm that your TCL TV meets BOTH of the following criteria:

- The firmware file name matches your specific TV model
- Your TV is experiencing problems or technical issues

* If your TV is not experiencing any issues, DO NOT update the firmware



Instructions

- 1) Load the firmware update file “MERGE.bin” onto a USB flash disk.
- 2) Take the USB flash disk and plug it into the USB port on the TV.
- 3) Set TV to standby status, press “Power” button on the TV for 5 seconds, and the TV will automatically update.

Note: Standby status is when the TV is off, but the indicator light on the front is lit, to indicate that it is plugged in.

Warning: Failure to follow the above instructions will result in damage to your TV!

If you have any questions, please call customer service 9am-9pm (EST)

US: 877-300-8837

HI, AK, PR: 877-300-1269