



# Hi! Let's get started.





### What's in the box









TCL Roku TV

TV stands

Power cable

Cable clip







4 x Phillips screws (M5X35mm)


2 x AA batteries for remote



TV remote

In-ear headphones

### What you need



#### For additional support, please see User Manual at: www.TCLUSA.com/support

Key things to know: A paid subscription or other payments may be required for some streaming channels. Channel availability subject to change and varies by country.

# Step 1 Set up your TV

Ready for the step-by-step? You're only minutes away from TV bliss!

#### **Remove** your TV from the box


Be careful, it's heavy!


#### To mount on a wall

Follow the instructions that come with the wall mount.

#### To use the stand

- A To prevent damage to the screen, carefully place your TV on a soft, cushioned surface.
- B Put the column of the stands into the TV, align the stands with the screw holes located on the TV.
- c Secure the stands to the TV with four (4) screws.





There are three slots on the back of the machine. Insert the cable clip into one of the slot to help you manage your cables!

# Step 2 Power up

In this step, we'll make sure all systems are GO!

**Power your TV remote** by inserting the included batteries.

**Connect** your power cable to the TV, then plug it in to the wall outlet.

# **Connect other devices** by refrencing port label and descriptions on the bottom of page 5.

**Power Tip!** Always replace dead batteries with two brand-new batteries from the same manufacturer. Never use damaged batteries. If your remote gets warm/hot during use, discontinue use and contact customer support immediately at www.TCLUSA.com/support.

### Step 3 Grab your remote

The TV remote should feel right at home in your hand. We designed it to be incredibly intuitive for watching TV and navigating on-screen menus. Plus, this one includes a headphone jack for the included in-ear headphones!

# First a couple of fun-facts about your Roku TV enhanced remote.

- It can hush your TV.When you plug headphones into the headphone jack, the TV is automatically muted. Use the Volume UP and DOWN buttons on the side of your remote to control the volume of your headphones to your liking.
- Using your remotes voice search feature lets you search through the widest selection of channels by actor, title, or director
- Can't find your remote? Press the left or right navigation button on the back of the TV to bring up the Quick Menu. Highlight the Find Remote option and the missing remote will make a sound so you can find it.

#### Here's some buttons you should know about.

- A POWER Turn TV on and off
- B BACK Return to previous screen
- C HOME Return to Roku Home screen
- D VOLUME Raise and lower volume
- **E INSTANT REPLAY** Replay last 7 seconds of streaming video
- F OPTIONS View more options
- G RWD SCAN Rewind streaming video, scroll left one page at a time
- H FWD SCAN Fast forward streaming video, scroll right one page at a time
- I VOICE SEARCH Search content through your voice after prompting "Speak Now"
- J IN-EAR HEADPHONES JACK Plug in your in-ear headphones here



- - Tip! The (\*) button gives you easy access to picture settings, display options, and more. Try it on every screen!

Step 4 Complete guided setup

Establish your network connection

### It's the final stretch—hurray!

#### Let's Connect

Your TV will automatically detect wireless networks in your area. Have your network name and password handy and follow the easy on-screen instructions. For the highest performance connection, you can also connect using an Ethernet cable.

Once you're connected, your TV will automatically update with the latest software—plus you can start streaming the entertainment you know and love. Unlike other TVs, your new TCL • Roku TV automatically receives regular software updates in the background when it's connected to the internet. This allows it to give you a better and better experience.

If you aren't ready to connect your TV to a wireless network, you can still use it as a regular TV.

### And setup is done...congratulations!

Continue using the remote to personalize your Home screen and channel line-up, stream movies, and so much more.


If you have an antenna or cable connected, just click the tuner tile to watch broadcast TV channels. The fun has just begun!



Your Roku account: During Guided Setup, you'll be prompted to create your Roku account online at **roku.com/link**. Your TV will generate a unique code that links your TV to your new account.

Roku accounts are free, and while a valid credit card is recommended, it is not required. If you choose to register with a credit card, you will be able to seamlessly rent movies, TV shows and download apps without having to enter in your credit card information each time. A unique PIN can be added to the account to prevent unauthorized purchases.

### Get to know your TV




#### A STATUS LIGHT Glows when the TV is in standby, flashes when the TV is busy, flashes once with each button press of the remote control.

**IR RECEIVER** Receives signal from the TV remote.

B COMPOSITE AV IN If your device isn't able to connect using HDMI\*, connect to your TV using standard red/white/vellow cables.

TV SIDE



# Viewing 4K Ultra HD Content

#### **4K UHD Spotlight Channel**

The Roku 4K UHD Spotlight channel features many movies and TV shows available in 4K UHD resolution from streaming services such as Netflix, Amazon Video, VUDU, and more.

Key things to know: A paid subscription or other payments may be required for some channels. Channel availability subject to change and varies by country. 4K content will not be available on all channels.

#### **Next Generation 4K Ultra HD Devices**

With HDMI inputs supporting the latest HDMI 2.0 with HDCP2.2 standards, connect next-gen game systems, Ultra HD blu-ray players and more to enjoy highest-quality 4K Ultra HD sources.

#### Upscale 1080p HD to 4K Ultra HD

Enjoy your favorite shows upscaled to near 4K Ultra HD quality with TCL Creative Pro Plus upscaling.



## Connecting brings out your TV's full potential!

You'll have access to more than 3,000 streaming channels\*.

#### Make any night a movie night

More than 35,000 movies to choose from, across all major streaming movie channels like Netflix, Amazon Video, Google Play, VUDU, and more.\*

#### Get in the groove

Stream music from one of 120 music channels like Pandora, VEVO and Spotify. Access your entire MP3 collection instantly with Amazon Cloud Player or the Roku Media Player.

#### **Explore your passions**

In addition to popular streaming channels like HBO NOW, SHOWTIME, PBS Kids, and FOX NOW, your TCL • Roku TV also offers hundreds of streaming channels to fuel your passions – including fitness, cooking, religion, outdoors, international programming, and much more.

#### Enjoy FREE trials of popular channels

In addition to popular streaming channels like HBO NOW, SHOWTIME, PBS Kids, and FOX NOW, your TCL • Roku TV also offers hundreds of streaming channels to fuel your passions – including fitness, cooking, religion, outdoors, international programming, and much more.

<sup>\*</sup>Subscription or other payment may be required to access certain channels. Content may not be available in all areas in which the TCL Roku TVs are sold and channel availability is subject to change. \*\*Cancel before free trial ends to avoid subscription fees. Credit card may be required.

## Troubleshooting

Having trouble completing the guided setup? Don't worry, it's usually an easy fix.

#### **4K Ultra HD Picture Quality**

- 4K Ultra HD picture quality is largely dependent on the source. Make sure your source content is 4K UHD.
- To stream 4K Ultra HD content, we recommend a broadband speed of 16 Mbps or more for optimum viewing.
- For Cable, Satellite, Gaming Consoles, and Blu-Ray players, we recommend using "High-Speed HDMI cables."

#### **Cannot connect to wireless network**

- Select the correct wireless network name and verify the password entered (case sensitive).
- Relocate the router from objects that interfere with performance (cordless phones, baby monitors, etc. ).
- Reboot the router by disconnecting the power for more than 2 minutes and reconnect.

#### What is the remote code for programming my Universal or Cable/Satellite box remote control

• Please visit www.tclusa.com/remotecodes

#### My picture is too small (black bars on the side)

- Play your movie/video and press the (\*) asterisk button.
- Select Advanced Picture Settings.
- Select **Picture Size**, select the picture size of your preference.

# Problems connecting my cable/satellite box or antenna through a coax cable

- Make sure the cable connections to the TV and your device are securely fastened
- Select cable/satellite box or antenna TV input
- Select "start finding channels" and follow the on-screen instructions to perform a full channel scan

#### **ELECTRONICS RECYCLING INFORMATION FOR CONSUMERS**

TCL strives to provide a high level of service to our customers and in the communities we serve, and recommends that consumers always look for a recycling or reuse alternative to throwing away televisions and other electronics. We encourage customers to recycle end-of-life electronic devices using one of the many convenient methods available today. In many states TCL has programs in place to enable consumers to drop-off and recycle televisions free of charge. For information on electronics recycling in all 50 states, including drop-off locations, please visit the "Electronics Recycling" area of the TCL USA website at **www.tclusa.com**.

### Need more help?

www.TCLUSA.com/support

877-300-8837



Copyright © 2016 by Roku, Inc. All rights reserved. Roku TV, and the Roku logo are owned by Roku, Inc. TCL and the TCL logo are owned by TTE Technology, Inc. Other brand and product names are the trademarks or registered trademarks of their respective owners