

Installation Instructions JUNCTION BOX Model FI-5002

This information provides the instructions for how to install the Junction Box FI-5002.


The FI-5002 has six CAN bus (NMEA2000) drop ports for use with the CAN bus (NMEA2000) network.

Package Contents

Name	Type	Code No.	Qty
Junction Box	FI-5002	-	1
Self-tapping Screw	4×20 SUS304	000-158-850-10	2
Cable Tie	T18R	000-167-891-10	9
Power Cable	FI-5002-POWERCABLE	000-166-954-10	1

Procedure

1. Remove the cover of the Junction Box.
2. Fix the Junction Box to the mounting location with two self-tapping screws ($\phi 4 \times 20$, supplied).



3. Connect the cables to applicable connector, referring to the interconnection diagram provided in the operator's manual or installation manual of a device connected to the Junction Box.
4. Fasten the cables to the cable clamp with the supplied cable ties.
5. Close the cover of the Junction Box.

取付要領書 ジャンクションボックス 型式 FI-5002

本書は、ジャンクションボックス FI-5002 の取付け方法について記載しています。


本機を使用することで、最大 6 台の CAN bus (NMEA2000) 機器の信号をバックボーンケーブルにドロップすることができます。

同梱物

名称	型式	部品コード	数量
ジャンクションボックス	FI-5002	-	1
タッピンネジ	4×20 SUS304	000-158-850-10	2
束線バンド	T18R	000-167-891-10	9
電源ケーブル	FI-5002-POWERCABLE	000-166-954-10	1

取付け手順

1. ジャンクションボックスカバーを手で取り外します。
2. 付属のタッピンネジ (φ4×20、2本) を使って、ジャンクションボックス本体を船内に取り付けます。



3. 本機に接続する機器の取扱説明書または装備要領書を参照して、各ケーブルを内部のコネクタに配線します。
4. 付属の束線バンドを使って、各ケーブルをケーブルクランプに固定します。
5. ジャンクションボックスカバーを元に戻します。